



**Style 6033 MINI UNIVERSAL CONTROL  
INSTALLATION, OPERATION & MAINTENANCE MANUAL**



# TABLE OF CONTENTS

<b>0. SAFETY SUMMARY</b>	<b>4</b>
<b>1.1 INTRODUCTION</b>	<b>5</b>
1.1 Safety Precautions.....	5
1.2 Introduction.....	5
1.3 Description.....	5
1.4 Technical Information.....	6
1.4.1 Power Requirements	6
1.4.2 Environmental Specifications Requirements.	6
<b>2. INSTALLATION</b>	<b>7</b>
2.1 Introduction.....	7
2.2 Unpacking.....	7
2.3 Attaching to vehicle.....	8
2.4 Cable(s) Installation.....	9
2.4.1 DC Power Cable	9
2.5 Vehicle Interface Cable.....	10
2.5.1 Vehicle interface Connector (Gray) Pin-out	10
2.5.2 J1939 Vehicle CAN Bus (Optional)	10
2.5.3 V-MUX Communication Bus (Optional)	11
2.5.4 Relay Outputs	11
2.6 Device I/O Cable.....	13
2.6.1 Device I/O Connector (Black) Pin-out	13
2.6.2 12/24 Power Out	13
2.6.3 Switch Inputs	14
2.6.4 Analog Inputs	14
2.7 Pre-operational Check	14
<b>3. OPERATING INSTRUCTIONS</b>	<b>15</b>
3.1 Theory of Operation.....	15
3.2 Description of Switch Functions.....	15
3.2.1 Extend Switch	15
3.2.2 Retract Switch	15
3.3 Description of Relay Output Functions.....	15
3.3.1 Hi-Riser Extended.....	15
3.3.2 Hi-Riser Retracted.....	15
3.4 Priority of Command Inputs.....	16
3.5 Normal Operation.....	16
<b>4. MAINTENANCE AND SERVICE INSTRUCTIONS</b>	<b>17</b>
4.1 Maintenance Instructions.....	17
4.2 Troubleshooting Electrical.....	17
4.2.1 Operating Environment	17
4.2.2 Common Electrical Issues	17
4.3 Akroview Software.....	17
<b>5. MINI UNIVERSAL VARIANT DETAILS</b>	<b>18</b>
5.1 60330003 Monitor Hi-Riser Control.....	18
<b>6. REVISIONS</b>	<b>18</b>

## LIST OF ILLUSTRATIONS

Figure 1-1	Mini Universal Control.....	5
Figure 2-1	Mini Universal Mounting Hole Locations.....	8
Figure 2-2	Vehicle Battery Connection.....	9
Figure 2-3	Deutsch DTM06-12SA-E007 (from rear).....	10
Figure 2-4	Relay Contact Output Wiring.....	11
Figure 2-5	J1939 CAN Wiring.....	12
Figure 2-6	Deutsch DTM06-12SB-E007 (from rear).....	13
Figure 2-7	Switch Input Wiring.....	14




## LIST OF TABLES

Table 2-1	Tools and Materials Required for Installation.....	7
Table 2-2	DC Power Connector Pin-out.....	9
Table 2-3	Vehicle Interface Connector Pin-out.....	13
Table 2-4	Device I/O Connector Pin-out.....	18

## SAFETY SUMMARY












### SIGNAL WORD DEFINITION

Per the ANSI Z535.4 standard, the following signal words and definitions are used to indicate hazardous situations:

-  **DANGER** DANGER indicates an imminently hazardous situation that, if not avoided, will result in death or serious injury.
-  **WARNING** WARNING indicates a potentially hazardous situation that, if not avoided, could result in death or serious injury.
-  **CAUTION** CAUTION indicates a potentially hazardous situation that, if not avoided, may result in minor or moderate injury. It is also used to alert against unsafe practices.

### SPECIFIC SAFETY PRECAUTIONS

The following are safety precautions that are related to specific procedures and therefore appear elsewhere in this publication for emphasis. These are recommended precautions that personnel must understand and apply during specific phases of installation, operation and maintenance.

-  **WARNING** For outdoor use only. Do not use in areas that have been classified as hazardous as defined in Article 500 of the National Electric Code.
-  **WARNING** Make sure all power has been disconnected and disable flow prior to performing maintenance.
-  **WARNING** Only trained and qualified personnel should perform installation, adjustments, and servicing. Only a properly trained and qualified certified electrician should perform electric installations and service.
-  **WARNING** DO NOT stow or deploy the monitor/turret while flowing. Pressing the stow or deploy buttons causes the nozzle to move automatically and the water stream may cause damage to equipment or injury to personnel.
-  **WARNING** DO NOT install shutoffs on the outlet of the monitor/turret. Shutoffs increase the potential for pressure surges due to water hammer, which have the potential to cause an injury or damage to the monitor/turret.
-  **WARNING** Keep all personnel out of the Danger Zone in front of the outlet of the nozzle when the water source is attached. Dangerous flow velocities can cause serious injury.
-  **CAUTION** Tangled cables can cause equipment damage. Ensure control cables are not tangled and are free to pay out as monitor/turret is operated.
-  **CAUTION** All operators must read the Operation section of this manual and be properly trained.
-  **CAUTION** Use only appropriate Akron Brass Company nozzles. Use of any other nozzles could affect the speed or operation of the monitor/turret.
-  **CAUTION** Make the connection of the vehicle and/or auxiliary battery the final step.
-  **CAUTION** The monitor/turret contains moving parts. Keep hands, fingers, and objects away from pinch points.

# CHAPTER 1

## INTRODUCTION

### 1.1 SAFETY PRECAUTIONS

Refer to the Safety Summary for precautions to be observed while operating or servicing this equipment.

### 1.2 INTRODUCTION

This manual covers the installation, operation, troubleshooting and maintenance instructions for the Style 6033 Mini Universal Control. The manual should be reviewed in its entirety. This manual is intended to provide installation, operation and maintenance information for Mini Universal configurations in general. Contact the Akron Brass factory with any additional questions before performing any procedures outlined in this manual.

### 1.3 DESCRIPTION

The Mini Universal is a product used to control Akron Brass single motor devices such as electrically actuated valves and telescoping risers. The unit is designed for installation on any vehicle for the purpose of providing control of these devices. Refer to Figure 1-1 for identification of the Mini Universal Control Box.

**Figure 1-1**

**Mini Universal Control**



## 1.4 TECHNICAL INFORMATION

### 1.4.1 Power Requirements

The Mini Universal will operate from either 12 or 24 volt DC power with no customer changes necessary, although electrically actuated valves and telescoping risers must be ordered as 12 or 24 volt for their proper operation. While the Mini Universal can operate below 10 volts, for optimum performance, a minimum of 11 volts (for 12 volt monitors/turrets, 22 volts for 24 volt monitors/turrets) is required at the Mini Universal connector. The DC power is internally protected with a 30 amp non-serviceable fuse. This fuse is strictly for wiring protection and should never need replacement under normal conditions. It is recommended that an external 20 amp slow blow fuse be placed in series with the vehicle battery positive lead. The DC power for the Mini Universal is supplied through a 2 pin Deutsch connector. The DC power connects to pins 1 and 2, and they accept up to 12 AWG wire. See section 2.4.1 for pin-out information. The electronic system has built-in reverse polarity protection. Long runs of cable can introduce voltage/power loss. For long runs, it may be necessary to add an intermediate junction box fed by 10 AWG or heavier wiring with a short 12 AWG run applied to the Mini Universal. If you need assistance in assessing wiring needs associated with long wiring runs, contact Akron Brass technical support.

**INPUT POWER REQUIREMENT:** 12VDC (Min: 11VDC; Max: 14VDC) OR  
24VDC (Min: 22VDC; Max: 28VDC)

**RECOMMENDED POWER WIRE SIZE:** 12VDC: 12AWG (see above discussion)  
24VDC: 12AWG

**REQUIRED EXTERNAL FUSE:** 12VDC: 20 amp Slow Blow  
24VDC: 10 amp Slow Blow

**MAX CONTINUOUS AMP DRAW:** (see spec. sheet for device being driven)

**PEAK AMP DRAW:** 50amp for 100ms for valve (100amp for 3406 Hi-Riser)

### 1.4.2 Environmental Specifications Requirements

The Mini Universal has been designed to be mounted on a vehicle and tolerate the harsh environments encountered in this application. The environmental specifications are listed below:

Operating Temperature Range: -40°C - 55°C

Enclosure Environmental Rating: IP67 Equivalent

## CHAPTER 2 INSTALLATION

### **⚠ CAUTION**

Only trained and qualified personnel should perform installation, adjustments, and servicing. Only a properly trained and qualified certified electrician should perform electric installations and service.

### **⚠ CAUTION**

Make the connection of the vehicle and/or auxiliary battery the final step.

### 2.1 INTRODUCTION

The Mini Universal has been designed to provide ease of installation. This section of the manual provides the procedures that must be followed to insure a successful installation. Be sure to read and understand the entire installation procedure before you begin.

Table 2-1 provides a list of tools and materials required to install and test the Mini Universal.

Wrenches	Deutsch Crimping tool
Screwdrivers	Wire cutter/stripper
1/4-20, M5, or M6 Mounting Hardware (2 req'd)	Multimeter (to verify power is turned OFF)
Torque wrench	Clean Shop Rags
Akron Brass 122365 Connector Kit (Included)	

Table 2-1 Tools and Materials Required for Installation

### 2.2 UNPACKING

Unpack the Mini Universal as follows:

Carefully open and remove all parts from shipping container.

Inspect for any shipping damage. If damage has occurred, notify carrier.

Be sure that all components are included and that the required tools are readily available.

## 2.3 ATTACHING TO VEHICLE

If the Mini Universal is to be mounted in a well, be certain that adequate drainage is provided. While the unit has been designed to withstand adverse environmental conditions, it cannot be submerged. In the case of use with a 3406 Riser, the Mini Universal is mounted directly to the side of the Riser on pre-threaded bosses.

The Mini Universal has one option for mounting:


Through hole mounting. The through hole mounting holes provided on the Mini Universal are .29 inches in diameter and suitable for 1/4"-20, M5 or M5 screws. These allow inserting screws from the top side and into threaded holes on the customer's back panel.

Mounting hole locations for the above method is shown in Figure 2-1. Please note that it is important that the mounting surface be flat. Sufficient room should also be allowed in mounting location to insure cabling does not have sharp bends close to the connectors.

**DO NOT OVERTIGHTEN SCREWS AS ENCLOSURE COULD BE DAMAGED.**

**Figure 2-1**

**Mini Universal Mounting Hole Locations**





## 2.4 CABLE(S) INSTALLATION

### 2.4.1 DC Power Cable

This 2 pin connector provides a connection point for power from the vehicle. The recommended connector for use on the customer harness is a Deutsch part number DTP06-2S-E003 or equivalent. The wires are best crimped in the pins although careful soldering is possible. A crimping tool is available from Ladd Industries part number HDT-48-00. Please refer to Table 2-2 and Figure 2-2 for pin-out information. The Mini Universal normally comes with a mating connector kit. NOTE: For ease of installation, a separate connector kit including connector, pins, and sealing plugs (for unused pins) can be ordered as part number 122365 from Akron Brass.


Pin Number	Function	Wire Color on Mini
1	12/24 Battery Power	Red
2	Ground/Common	Black

Table 2-2 DC Power Connector Pin-out

The vehicle battery must be connected to pins 1 and 2 of the DC Power connector. Pin 1 must connect to +Battery and pin 2 must connect to –Battery (usually chassis, ground, or common). It is recommended that a 20 amp slow blow fuse be connected in series with the +Battery wire. Refer to section 1.4.1 for additional information.

Figure 2-2

#### Vehicle Battery Connection




2.5 VEHICLE INTERFACE CABLE

This gray 12 pin connector provides a connection point for signals to/from the vehicle. The Vehicle Interface connector requires a Deutsch DTM06-12SA-E007 or equivalent connector on the user harness. This connector should be included in the 122365 connector kit that came with the Mini Universal. In the event of troubleshooting, Table 2- 3 is provided for reference.

2.5.1 Vehicle interface Connector (Gray) Pin-out

Pin Number	Type	Function	Comments
1	12/24 Power Out	Power for remote device	1.1 Amp Max.
2	Ground/Common		
3	CAN-H	CAN Network	J1939
4	CAN-L		
5	12/24 Power Out	Power for remote device	1.1 Amp Max.
6	Ground/Common		
7	Data B (+)	RS-485 Network	VMUX or RS-485
8	Data A (-)		
9	Relay Contact		2 Amps Max.
10			
11	Relay Contact		2 Amps Max.
12			


Vehicle Interface Connector Pin-out



2.5.2 J1939 Vehicle CAN Bus (Optional)

The Mini Universal J1939 Vehicle CAN Bus is available on pins 3 and 4. Pin 3 is CAN-HI, and pin 4 is CAN-LO. Preferred connection to these pins should be made with J1939/11 compliant wiring. See Figure 2-5 for additional details. NOTE: Termination resistors are critical to reliable performance. Pins 1 and 2 can be utilized to power a remote CAN device. Pin 1 is fused with a self-resetting fuse at 1.1 amps. If this optional feature is not used, it is recommended these pin locations be fitted with Deutsch pin sealing plugs.

### Figure 2-5



ITEM	MANUFACTURER	DESCRIPTION	A-3 PART NUMBER
A	Deutch IPD	HD06-34-39CE PLUG	702758/28400
B	Deutch IPD	HD06-35-40EP1 PLUG	742022/28400
C	Deutch IPD	HD06-35-P016 WEDGE LOCK	742020
D	Deutch IPD	HD06-35-P016 TERMINATING RESISTOR ASSEMBLY	742020
E	Deutch IPD	HD06-34-P007 Y- RECEPT ACK	285806
F	Deutch IPD	HD06-34-EP1 PLUG W/ V35-1939-P012 WEDGE LOCK	742204 / 284000
F	Deutch IPD	HD06-43 W/ V35 WEDGE LOCK	742204 / 284000
G	Champlain Wire	SAE1939/1802HBLK or Nychem 208E0309 or 208E0307 208E0305 or 208E0304 208E0303 208E0302 208E0301 208E0300 208E0299 or 208E0298 208E0297 or 208E0296 208E0295 or 208E0294 208E0293 or 208E0292 208E0291 208E0290 208E0289 or 208E0288 208E0287 or 208E0286 208E0285 or 208E0284 208E0283 or 208E0282 208E0281 208E0280 208E0279 or 208E0278 208E0277 or 208E0276 208E0275 or 208E0274 208E0273 or 208E0272 208E0271 208E0270 208E0269 or 208E0268 208E0267 or 208E0266 208E0265 or 208E0264 208E0263 or 208E0262 208E0261 208E0260 208E0259 or 208E0258 208E0257 or 208E0256 208E0255 or 208E0254 208E0253 or 208E0252 208E0251 208E0250 208E0249 or 208E0248 208E0247 or 208E0246 208E0245 or 208E0244 208E0243 or 208E0242 208E0241 208E0240 208E0239 or 208E0238 208E0237 or 208E0236 208E0235 or 208E0234 208E0233 or 208E0232 208E0231 208E0230 208E0229 or 208E0228 208E0227 or 208E0226 208E0225 or 208E0224 208E0223 or 208E0222 208E0221 208E0220 208E0219 or 208E0218 208E0217 or 208E0216 208E0215 or 208E0214 208E0213 or 208E0212 208E0211 208E0210 208E0209 or 208E0208 208E0207 or 208E0206 208E0205 or 208E0204 208E0203 or 208E0202 208E0201 208E0200 208E0199 or 208E0198 208E0197 or 208E0196 208E0195 or 208E0194 208E0193 or 208E0192 208E0191 208E0190 208E0189 or 208E0188 208E0187 or 208E0186 208E0185 or 208E0184 208E0183 or 208E0182 208E0181 208E0180 208E0179 or 208E0178 208E0177 or 208E0176 208E0175 or 208E0174 208E0173 or 208E0172 208E0171 208E0170 208E0169 or 208E0168 208E0167 or 208E0166 208E0165 or 208E0164 208E0163 or 208E0162 208E0161 208E0160 208E0159 or 208E0158 208E0157 or 208E0156 208E0155 or 208E0154 208E0153 or 208E0152 208E0151 208E0150 208E0149 or 208E0148 208E0147 or 208E0146 208E0145 or 208E0144 208E0143 or 208E0142 208E0141 208E0140 208E0139 or 208E0138 208E0137 or 208E0136 208E0135 or 208E0134 208E0133 or 208E0132 208E0131 208E0130 208E0129 or 208E0128 208E0127 or 208E0126 208E0125 or 208E0124 208E0123 or 208E0122 208E0121 208E0120 208E0119 or 208E0118 208E0117 or 208E0116 208E0115 or 208E0114 208E0113 or 208E0112 208E0111 208E0110 208E0109 or 208E0108 208E0107 or 208E0106 208E0105 or 208E0104 208E0103 or 208E0102 208E0101 208E0100 208E0099 or 208E0098 208E0097 or 208E0096 208E0095 or 208E0094 208E0093 or 208E0092 208E0091 208E0090 208E0089 or 208E0088 208E0087 or 208E0086 208E0085 or 208E0084 208E0083 or 208E0082 208E0081 208E0080 208E0079 or 208E0078 208E0077 or 208E0076 208E0075 or 208E0074 208E0073 or 208E0072 208E0071 208E0070 208E0069 or 208E0068 208E0067 or 208E0066 208E0065 or 208E0064 208E0063 or 208E0062 208E0061 208E0060 208E0059 or 208E0058 208E0057 or 208E0056 208E0055 or 208E0054 208E0053 or 208E0052 208E0051 208E0050 208E0049 or 208E0048 208E0047 or 208E0046 208E0045 or 208E0044 208E0043 or 208E0042 208E0041 208E0040 208E0039 or 208E0038 208E0037 or 208E0036 208E0035 or 208E0034 208E0033 or 208E0032 208E0031 208E0030 208E0029 or 208E0028 208E0027 or 208E0026 208E0025 or 208E0024 208E0023 or 208E0022 208E0021 208E0020 208E0019 or 208E0018 208E0017 or 208E0016 208E0015 or 208E0014 208E0013 or 208E0012 208E0011 208E0010 208E0009 or 208E0008 208E0007 or 208E0006 208E0005 or 208E0004 208E0003 or 208E0002 208E0001 208E0000	704747 / 785015

## J1939 CAN Wiring

## 2.6 DEVICE I/O CABLE

This black 12 pin connector provides a connection point for I/O signals to/from the device and the vehicle. The recommended connector is a Deutsch part number Deutsch DTM06-12SB-E007. Please refer to Table 2-4 and Figure 2-3 for pin-out information. NOTE: For ease of installation, a connector kit including connector, pins, and sealing plugs (for unused pins) is included with the Mini Universal, but is available separately as part number 122365 from Akron Brass.


### 2.6.1 Device I/O Connector (Black) P in-out

Pin Number	Type	Function	Comments
1	12/24 Power Out	Power for switches	0.1 Amp Max.
2	Switch Input #1		
3	Switch Input #2		
4	Switch Input #3		
5	Switch Input #4		
6	Switch Input #5		
7	Ground/Common		
8	Analog In #1		(0 to 5 VDC)
9	Analog In #2		(0 to 5 VDC)
10	Analog In #3		(0 to 5 VDC)
11	Analog In #4		(4 to 20 ma.)
12	Analog Exc.	Sensor Power	(5 VDC)

Table 2-4 Device I/O Connector Pin-out

Figure 2-4

Deutsch DTM06-12SA-E007 (from rear)



### 2.6.2 12/24 Power Out


Pin 1 supplies power out for use of powering switches. It is internally fused by a self-resetting fuse, and will be at roughly the same potential as the DC power coming in. Use of this pin is optional, but connecting switch inputs to external battery potential carries with it the restriction noted at the end of section 2.6.3.

### 2.6.3 Switch Inputs

Switch Inputs #1 to #5 (pins 2 to 6) are primarily intended for toggle switch input. Their function varies depending on configuration. An Akron Brass Operator Station can be used or users can provide their own switch inputs. Please refer to the Control Drawing for the particular version Mini Universal for their assigned function. The Mini Universal version is identified by a barcode label on the outside of the enclosure back that includes the part number (6033XXXX) and revision level. Each input recognizes three distinct states – open, connected to +Bat, and connected to –Bat. A typical toggle switch connection is shown in Figure 2-4. Use of relay contacts could also be implemented if care is taken to insure there is never a case in which the battery is shorted out. A form C contact is a good choice in which the common is tied to the switch input.

**Figure 2-7**

**Switch Input Wiring**



Unused switch input pins should be fitted with Deutsch pin sealing plugs. These are included in the connector kit from Akron Brass.

**NOTE:** If any of the switch inputs are still connected to battery + after power is removed to the Mini Universal, the control will not properly shut down due to leakage currents through the inputs. Insure that battery + for the switch inputs is disconnected along with power to the Mini Universal.

### 2.6.4 Analog Inputs

The Mini Universal has four analog inputs. Inputs #1 to #3 (on pins 8 to 10 respectively) are for use with 0 to 5 volts DC signals. Input #4 (pin 11) is for use with 4 to 20 ma. signals. Pins 7 and 12 provide 5 volts DC excitation for use with appropriate transducers.

## 2.7 PRE-OPERATIONAL CHECK

### **⚠ WARNING**

Do not use in areas that have been classified as hazardous as defined in Article 500 of the National Electric Code.

Before operating the Mini Universal and monitor/turret, be sure that there are no potential obstructions. Visually inspect the unit for any damage. If damage is apparent, do not use the system. Have it serviced prior to use. Check for any objects which might obstruct motion of the monitor/turret or cause binding. Remove any material that may hinder monitor/turret function.

## CHAPTER 3

### OPERATING INSTRUCTIONS



All operators must read the Operation section of this manual and be properly trained.



Keep personnel clear of monitor/turret discharge path during operation.



For outdoor use only. Do not use in areas that have been classified as hazardous as defined in Article 500 of the National Electric Code.

#### 3.1 THEORY OF OPERATION

The Mini Universal control system is based on a distributed intelligence control structure. Each device in the system has a circuit board with an embedded micro controller. These devices can include (but are not limited to): the 6032 Universal II Control Box, the 6033 Mini Universal, the 6034 CAN Operator Interface, the 6035 CAN Joystick, the 6036 CAN Direction Indicator, the 6037 CAN Wireless Interface, and the associated handheld Remote Control(s). These boards “talk” to each other over an SAE J1939 compliant CAN serial communications link.

The 6033 Control device is a software-defined universal controller. Its inputs and outputs are pre-programmed at the factory to match the particular device it is used with. Please refer to the CHAPTER 5 for the particular version Mini Universal for their assigned function. The Mini Universal version is identified by a barcode label on the outside of the enclosure that includes the part number (6033XXXX) and revision level.

#### 3.2 DESCRIPTION OF SWITCH FUNCTIONS

The Mini Universal has five switch inputs located on the Device I/O (Black) connector (see Figure 2-6 and Table -2-4). Below are the various functions that the Mini Universal switch inputs can provide. Each variant of 6033 will have some combination of these, but not necessarily all or in the order presented here.

**NOTE:** The Mini Universal switch inputs are three-state inputs. Refer to section 2.6.3 for additional information and proper wiring.

##### 3.2.1 Extend Switch

This switch input provides capability for extending the Hi-Riser when deploying the monitor/turret with which it is associated. This switch input is typically driven by the relay output of a Universal I in legacy applications. Connection to +Battery by switch, hardwiring, or some other appropriate device will initiate operation. The Hi-Riser will extend until the hard stop at the full extent of travel is reached.

##### 3.2.2 Retract Switch

This switch input provides capability for retracting the Hi-Riser when stowing the monitor/turret with which it is associated. This switch input is typically driven by the relay output of a Universal I in legacy applications. Connection to +Battery by switch, hardwiring, or some other appropriate device will initiate operation. The Hi-Riser will retract until the hard stop at the full extent of travel is reached.

#### 3.3 DESCRIPTION OF RELAY OUTPUT FUNCTIONS

The Mini Universal has two relay outputs located on the vehicle interface connector (see Figure 2-4 and Table 2-3). Below are the various functions that the Mini Universal relay outputs can provide. Each variant of 6033 will have some combination of these, but not necessarily all or in the order presented here.

**NOTE:** The Mini Universal relay outputs are floating contacts. Refer to section 2.5.4 for additional information and proper wiring.

##### 3.3.1 Hi-Riser Extended

The relay contact output closes when the Hi-Riser has completed extending and remains closed until the monitor moves away from that position. This relay contact is from a latching relay, and therefore maintains its state regardless of power to the Mini Universal.

##### 3.3.2 Hi-Riser Retracted

The relay contact output closes when the Hi-Riser has completed retracting and remains closed until the monitor moves away from that position. This relay contact is from a latching relay, and therefore maintains its state regardless of power to the Mini Universal.

### **3.4 PRIORITY OF COMMAND INPUTS**

Command inputs can have multiple sources. One source is from switch inputs as outlined in section 3.2. Command inputs can also come from J1939 CAN messages. This type command input takes the form of proprietary J1939 messages issued by the 6032 Universal II control. The switch inputs have the highest priority. Then CAN network commands take the next lower priority. Thus a Master/Slave hierarchy can be established by using the appropriate command method.

### **3.5 NORMAL OPERATION**

The device may be moved by any of the command inputs mentioned above with the corresponding action occurring. For instance, if a Deploy switch on a Universal II monitor/turret control is activated, the Universal II will issue a CAN message to the Mini Universal and the Hi-Riser will move the monitor/turret upward for continuation of the Deploy sequence on the monitor/turret. If a Stow switch on a Universal monitor/turret control is activated, the Universal II will issue a CAN message to the Mini Universal and the Hi-Riser will move the monitor/turret downward for completion of the Stow sequence on the monitor/turret.

## CHAPTER 4

### MAINTENANCE AND SERVICE INSTRUCTIONS

#### 4.1 MAINTENANCE INSTRUCTIONS

The Mini Universal has no user-serviceable parts, but steps can be taken to extend its trouble-free operation.

Periodically check cabling for insulation cracking and wire connections for frayed wires.

Insure there is no standing water around the enclosure.

Check all mounting hardware to insure proper tightness.

#### 4.2 TROUBLESHOOTING ELECTRICAL

##### 4.2.1 Operating Environment

One of the most common causes of improper operation is trying to operate outside of the stated system requirements.

(See section 1.4.1 for DC power requirements). A good method of checking the voltage at the Mini Universal is to connect a voltmeter to the wires/pins of the Peripheral Power Output on the DC Power/Signal cable (pins 22 and 25). Refer to section 2.4 and Figure 2-2 for additional information. This will give a good indication of power loss across the DC cabling. For long runs, it may be necessary to add an intermediate junction box in the DC cable so that DC power can be applied closer to the Mini Universal.

##### 4.2.2 Common Electrical Issues

Symptom	Potential Cause	What to Check	Solution
Totally Inoperative	Lack of Power	Remove the Power Cable connector from the Mini Universal box. Check for voltage approximately equal to vehicle battery voltage between pins 1 and 2.	If no measurable voltage is present, insure proper DC power is applied to pins 1 and 2. (See section 1.4.1 and section 2.4.1 for DC power requirements)
	Internal Fuse Blown	Leaving the Power/Signal Cable connected, remove the Device I/O Connector (Black). Check the voltage between pins 7 and 12 (Sensor Power) on the Mini Universal.	If approximately 5 volts exists between pins 7 and 12, and LED #3 is on, the internal fuse is blown. This fuse is not user-serviceable and indicates additional damage inside the control. Contact Akron Brass to return the Mini Universal for service or exchange.
	Motor or Motor wiring open	Is LED #3 on? If so, check Motor and associated wiring continuity	If no continuity, repair wiring and/or Motor.
Switches function properly, but CAN Joystick and other network devices do not	CAN bus is improperly wired	Check CAN bus wiring	Rewire CAN bus
	CAN bus is improperly terminated	Turn off system power and remove the Vehicle Interface Cable connector. Measure the resistance between pins 3 and 4.	If the resistance does not measure between 50 and 70 ohms, insure that the CAN network is properly terminated. (See section 2.5.2)

#### 4.3 AKROVIEW SOFTWARE

As with all of the Akron Brass CAN product family, the 6033 Mini Universal supports the Akroview Software. The software provides additional diagnostics as well as software updating and other capabilities. Contact Akron Brass for additional information on how you can obtain a copy of Akroview software.



## CHAPTER 5

### MINI UNIVERSAL VARIANT DETAILS

#### 5.1 60330003 MONITOR HI-RISER CONTROL

BLACK CONNECTOR		
Pin	Function	Configuration
1	12/24 Power Out	Vehicle Battery +
2	Switch Input #1	Retract Command Input (Active when connected to Pin #1)
3	Switch Input #2	Extend Command Input (Active when connected to Pin #1)
4	Switch Input #3	Unused
5	Switch Input #4	Unused
6	Switch Input #5	Unused
7	Ground/Common	Unused
8	Analog In #1	Unused
9	Analog In #2	Unused
10	Analog In #3	Unused
11	Analog In #4	Unused
12	Analog Exc.	Unused

GRAY CONNECTOR		
Pin	Function	Configuration
1	12/24 Power Out	Vehicle Battery +
2	Ground/Common	Retract Command Input (Active when connected to Pin #1)
3	CAN-H	Extend Command Input (Active when connected to Pin #1)
4	CAN-L	Unused
5	12/24 Power Out	Unused
6	Ground/Common	Unused
7	Data B (+)	Unused
8	Data A (-)	Unused
9	Relay Contact	Contact closes when Riser is fully retracted
10		
11	Relay Contact	Contact closes when Riser is fully extended
12		

NOTE: It is always best to consult the control drawing D-44488 for up to date details.

#### REVISIONS

Revision 0, October 2011: Initial Release.



### 2.5.3 V-MUX Communication Bus (Optional)

Connection to a VMUX communications bus is available on pins 7 and 8. Pin 7 is DATA B and Pin 8 is DATA A. Not all software versions support VMUX communication. Contact Akron Brass technical support for details of your particular version. Pins 5 and 6 can be utilized to power a remote VMUX device. Pin 5 is fused with a self-resetting fuse at 1.1 amps. If this optional feature is not used, it is recommended these pin locations be fitted with Deutsch pin sealing plugs. If this option is desired, please contact Akron Brass for additional details.

### 2.5.4 Relay Outputs

Two relay outputs are provided for indication of the state of the Mini Universal and its load. These two outputs are totally floating, and independent of each other. Additionally, they are latching relays and maintain their state regardless of whether the Mini Universal is powered or not. Pins 9 and 10 connect to one relay contact, and pins 11 and 12 connect to the other relay contact. Their function is defined in software at the factory. Please refer to the drawing for the version of 6033 in possession. The Mini Universal version is identified by a barcode label on the outside of the enclosure and located on the back that includes the part number (6033XXXX) and revision level.

**Figure 2-4**

#### Relay Contact Output Wiring

