




Style 8805

**Field Service Kit with
Metal Ball for:
8620 and 8820 Heavy Duty
Swing-Out™ Valves**

**Conversion Kit
for:
7620 and 7820 Swing-Out Valves**

**HEAVY DUTY
SWING-OUT VALVE**



△ Tighten to
25-30 ft-lbs.

PHONE: 330.264.5678 or 800.228.1161 | FAX: 330.264.2944 or
800.531.7335 | akronbrass.com REVISED: 7/10

WARRANTY AND DISCLAIMER: We warrant Akron Brass products for a period of five (5) years after purchase against defects in materials or workmanship. Akron Brass will repair or replace product which fails to satisfy this warranty. Repair or replacement shall be at the discretion of Akron Brass. Products must be promptly returned to Akron Brass for warranty service.

We will not be responsible for wear and tear, any improper installation, use, maintenance or storage, negligence of the owner or user, repair or modification after delivery, damage, failure to follow our instructions or recommendations or anything else beyond our control. **WE MAKE NO WARRANTIES, EXPRESS OR IMPLIED OTHER THAN THOSE INCLUDED IN THIS WARRANTY STATEMENT, AND WE DISCLAIM ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE.** Further, we will not be responsible for any consequential, incidental or indirect damages (including, but not limited to, any loss of profits) from any cause whatsoever. No person has authority to change this warranty.

© Akron Brass Company 2000 All rights reserved. No portion of this can be reproduced without the express written consent of Akron Brass Company.



Tested... Proven... Trusted.

ISO 9001 REGISTERED COMPANY

PARTS LIST AND REPAIR INSTRUCTIONS FOR HEAVY DUTY SWING-OUT™ VALVES

DISASSEMBLY

1. Turn the valve ball to the open position.
Note: If the Valve Handle needs to be removed, the position of the Handle and Stop Plate should first be noted before disassembly.
2. This Valve is designed to "Swing Out" for easy repair.

In order to swing the Valve, loosen the 4 sets of Adapter Bolts (21). Then remove 3 Bolt sets and rotate the Valve for easy repair. If the Valve cannot be rotated, remove the 4th set of Adapter Bolts.

3. Remove the 2 Seats (20) from the Valve Body (19). It may be necessary to partially close the Ball to grasp the lip of the Seat to remove.
4. Remove the Threaded Trunnion (18).
5. With the Valve in the open position, remove the Ball (16).
6. Remove the Ball Trunnion only if leakage has been detected in this area. To remove the Ball Trunnion (15), first remove the Handle Bolt (1), Washer (2), Bearing Brake (3) and Compression Spring (4). Then push the Ball Trunnion into the Valve cavity and remove the Thrust Washer (13) from the top of the Ball Trunnion. Next, remove the Nylon Bushing (5) from the upper Trunnion hole.

REASSEMBLY

1. Lubricate the O-Rings (14 & 17) with Parker O-Ring Lubricant or equivalent petroleum based lubricant. Be sure not to place any excess lubricant on the Seats or Ball, as this will collect dirt that may cause excess wear.
2. If the Ball and Ball Trunnion were removed proceed as follows, if not skip to Step 8.
3. Place Thrust Washer (13) on the Ball Trunnion (15).
4. Place O-Ring (14) in the recess of Ball Trunnion (15).
5. Insert the Ball Trunnion into the upper trunnion hole from inside the Valve.
6. Place Nylon Bushing (5), Compression Spring (4) and Bearing Brake (3) into the recess. Align the tabs on the Bearing Brake with the slots in the Body.
7. Replace the Stop Plate (6 or 11), Handle and any connection hardware. Be sure the tabs on the Bearing Brake are fitted into the slots of the Body.
8. Rotate the Ball Trunnion to accept the Ball. Insert the Ball into the Valve.
9. Place a new O-Ring (17) in the recess of Threaded Trunnion (18) and thread the trunnion into the Valve body.
10. WITH THE BALL IN THE OPEN POSITION, PLACE A NEW Seat (20) into the recess on each side of the Valve Body.
11. Return the Valve to its original position between the flanged adapters and loosely replace the 8 Bolts.
12. Close the Valve Ball and then tighten the flange bolts. Tighten the bolts in an "X" pattern using 25-30 foot pounds of torque.

DO NOT OVER TIGHTEN

13. Operate the Valve and inspect for leaks.

ITEM NO.	DESCRIPTION	QTY	8820†
1	Bolt	1	761065
2	Washer	1	784120
3	Bearing Brake w/ clip	1	704788
4	Compression Spring	1	768291
5	Nylon Bushing	1	735058
6	Stop Plate (TS/TSC Handle)	1	742073
7	Handle Hub (TS/TSC Handle)	1	721278
8	Cover (TSC Handle)	1	109177
9	Rod* (TS/TSC Handle) Std.	1	109146
10	Ball (TS/TSC Handle)	1	703080

ITEM NO.	DESCRIPTION	QTY	8820†
11	Stop Plate (R-1 Handle)	1	742095
12	R-1 Handle Std. Length	1	721237
13	Thrust Washer	1	784104
14	O-Ring**	1	757226
15	Ball Trunnion	1	773300
16	Valve Ball	1	119656

ITEM NO.	DESCRIPTION	QTY	8820†
17	O-Ring**	1	757198
18	Threaded Trunnion	1	773094
19	Body	1	116310
20	Seat***	2	769561
21	Bolt	8	761092
22	Valve Adapters*	2	

OPERATING AND MAINTENANCE INSTRUCTIONS

Always open and close valves slowly to minimize the effects of water hammer. Occasionally, flow water through all valves to clear dirt and debris.

Do not exceed 500 psi operating pressure.

See Drawing on opposite page.

* See current catalog for complete list.

** Parts in Service Kits

† For the repair of Style 8620 valves using various controllers on SZ handles, contact Akron Brass customer service for details


PARTS LIST AND INSTRUCTIONS FOR CONVERTING A VALVE TO A METAL BALL

Style 7620
Non Tork-Lok®
with Trunnion Retaining
Plate (#7)

Style 7820
Tork-Lok with
large stops built into
Trunnion Retaining
Plate (#7)

Style 7620
Non Tork-Lok with stops
in valve body and
separate stop
Plate (#4)

Style 7820
with separate stop
Plate (#4)



*See current catalog for complete handles and adapters. **Replace with Tork Lok Conversion Kit

ITEM NO.	DESCRIPTION	7620 with Trunnion Plate	7820 with Stops in Trunnion Plate	7620 with Separate Stop Plate	7820 with Separate Stop Plate
1	Handle Bolt	761065	761065	761065	761065
2	Handle Washer	784034	784034	784034	784034
3	Handle*				
4	Stop Plate RI-Hdle	N/A	N/A	742095	742095
4	Stop Plate TS-Hdle	N/A	N/A	N/A	742073
5	Trunnion Plate Screws	767090 (6)	767090 (6)	N/A	765028 (4)
6	Handle O-Ring	N/A	757054	N/A	757284
7	Trunnion Retaining Plate	105707	**	N/A	742089
8	Handle Trunnion	N/A	772092	772115	772142
9	Tork-Lok Spring	N/A	768210	N/A	768210
10	Ball Trunnion	772088	773149	772115	773149
11	Retaining Ring	758058	758058	N/A	758154
12	Trunnion O-Ring	757010	757010	757226	757010
13	Tork-Lok Sleeve	N/A	769172	N/A	N/A
14	7600 Handle Spacer	N/A	N/A	769310	N/A
15	Threaded Trunnion O-Ring	757022	757022	757022	757022
16	Threaded Trunnion	773094	773094	773094	773094
17	Complete Adapters*				
18	Adapter Bolts (8)	761016	761016	761016	761016
19	Ball	119656	119656	119656	119656
20	Seats (2)	769561	769561	769561	769561
21	Valve Body	103286	103286	103286	106309
22	TS Handle Rod --- 9 1/4"	N/A	109146	N/A	109146
23	TS Handle Ball	N/A	703080	N/A	703080
24	TS Handle Hub	N/A	721278	N/A	721278
25	TS Handle Cover	N/A	109177	N/A	109177

DISASSEMBLY—BALL AND SEATS

Note: This kit includes extra O-rings for the different variations of valve. Identify the correct replacement O-rings when removing the old ones.

1. Turn the valve to the open position.
2. If the valve can be rotated out of line, remove three pairs of adapter bolts (18) and loosen the fourth pair. Swing the valve out of the line. If the valve cannot be rotated out of line, remove all eight adapter bolts and take the valve out completely.

Note: If it is necessary to remove the handle, mark the position of the handle in relation to the ball position, and the orientation of the stop plate (4) if so equipped.

3. Remove the two seats (20) from the valve body (21). It may be necessary to partially close the ball and grasp the inside lip of the seat.
4. Remove the threaded trunnion (16). If necessary, use fine emery paper to clean up the smooth portion that fits into the ball. The ball should fit loosely on the trunnion.
5. Rotate the handle so that the slot in the top of the ball is parallel to the waterway. Remove the ball (19).

DISASSEMBLY—HANDLE AND TOP TRUNNION(S)

Note: If the valve is equipped with an electric actuator, do not disassemble this portion of the valve. The water tight seal will be broken and water may leak into the electronic controls chamber. If the valve is equipped with a standard type handle, it is not normally necessary to replace the O-ring under the handle or on the ball trunnion. Do not disassemble this portion of the valve unless there is a leak.

1. Remove the handle bolt (1) and washer (2).
2. Note the position of the handle relative to the groove in the top of the trunnion for reassembly purposes. Remove the handle (3) and the stop plate (4), handle O-ring (6) and handle spacer (14) if so equipped.
3. If the valve includes a trunnion retaining plate (7), note the position for reassembly purposes. Remove the trunnion plate screws (5).

Note: With flat head screws, one screw may be tighter than the others. Try to loosen all remaining screws before using excessive force on one.

If the valve does not have a retaining plate, remove the trunnion (10) by pushing it into the valve body.

4. Remove the trunnion retaining plate (7). If this plate was secured with socket head screws, the handle trunnion (8) should remain in the plate.
5. Remove the handle trunnion (8), if separate.
6. Remove the Tork-Lok® sleeve (13) and spring (9) subassembly if applicable.

Caution: Do not remove the spring from inside the sleeve.

7. Remove the ball trunnion (10) by pushing it from the inside of the valve.

REASSEMBLY—HANDLE AND TOP TRUNNION(S)

Note: Lubricate all O-rings with Parker O-Ring Lube or equivalent petroleum-based lubricant.

1. Replace the O-ring (12) on the ball trunnion (10) and reinstall the trunnion in the valve body.
2. Replace the Tork-Lok sleeve (13) and spring (9) subassembly and handle trunnion (8) if so equipped.

Note: The ears of the Tork-Lok spring must be aligned with the corresponding recess of the ball trunnion. The pilot shaft of the handle trunnion must fit into the hole in the center of the ball trunnion.

3. Reposition the trunnion retaining plate (7), if so equipped, and install the screws (5).

Note: For Tork-Lok valves with flat head screws, tighten all six screws until they just touch the plate before fully tightening any one screw. Yighten them in a criss-cross pattern. There should be a small gap between the plate and the valve body.

4. Install the handle O-ring (6), style 7600 handle spacer (14), and stop plate (4) as required.
5. Position the handle in the proper position, apply a small amount of Loctite 222 or equivalent to the handle bolt (1) and install the bolt with the handle washer (2). Immediately test the operation of the handle. If it appears to be hard to turn, loosen the handle bolt approximately 1/4 turn.

REASSEMBLY—BALL AND SEATS

1. Install the new O-ring (15) on the threaded trunnion (16).
2. Use a 10" or larger flat file to clean up the flat surface of the adapters and mating surfaces of the valve body. Remove any paint, corrosion or raised lip around the bolt holes.

Caution: Always file diagonally and keep the file touching both sides of the valve body. The surfaces must remain flat.

3. Rotate the handle so that the flats on the sides of the ball trunnion (10) are parallel to the waterway.
4. Install the new ball (19) over the ball trunnion and hold it in position.

Note: The ball included with this kit is a direct replacement when repairing a valve with a plastic ball.

5. Install the threaded trunnion so that it fits into the hole in the ball. Tighten the trunnion.
6. Place the new seats into the recesses on either side of the valve body (21).
7. Swing the valve body back into line or install the assembly. Loosely install the adapter bolts.
8. Turn the ball to the closed position.

Caution: The ball must be in the closed position before the adapter bolts are tightened.

9. Tighten the adapter bolts evenly in an X pattern using 25 - 30 Foot Pounds of torque.

DO NOT OVERTIGHTEN.

10. Operate the valve and test for leakage.

MAINTENANCE INSTRUCTIONS

Do not lubricate the ball or seats. Lubricants can collect dirt and grit which may cause excessive wear. Occasionally, flow water through all valves to clear dirt and debris.

OPERATING INSTRUCTIONS

Always open and close valves slowly.

Do not exceed 500 psi.