




INSTALLATION INSTRUCTIONS FOR STYLE 2775 HYDRANT MOUNT AND STYLE 2770 HYDRANT MOUNT/BRONCO ASSEMBLY OPERATING INSTRUCTIONS

1. Remove 2- $\frac{1}{2}$ " cap from hydrant.
2. Connect swivel end of Hydrant Mount/Bronco Assembly to hydrant and tighten swivel. It may be necessary to move the the Hydrant Mount/Bronco back and forth to ensure swivel tightens securely.
3. Tighten nuts on leg extensions (threaded stock) by hand until they are against the legs (tube). Keep tightening the nuts alternately with a wrench until there is no side motion and the leg extensions rigidly support the Hydrant Mount Assembly.
4. The Hydrant Mount and Bronco should be mounted as nearly vertical as possible.
5. Bolt the foot pads to the concrete pad, using the 4 anchor bolts and lock washers provided. Pre-drill 5/8 inch hole in concrete for bolts.
6. DO NOT flow water through the unit until it is bolted to a concrete pad.

⚠ WARNING: ALWAYS BOLT SUPPORT LEGS TO A RIGID CONCRETE PAD. THE MONITOR MAY BECOME UNSTABLE AND CAUSE INJURY IF OPERATED ABOVE THE RATED PRESSURE AND FLOW. DO NOT OPERATE OVER 100 PSI OR 1200 GPM.





Tested.. Proven.. Trusted.

ISO 9001 REGISTERED COMPANY

PHONE: 330.264.5678 or 800.228.1161 | FAX: 330.264.2944 or 800.531.7335 | akronbrass.com

REVISED: 10/12

WARRANTY AND DISCLAIMER: We warrant Akron Brass products for a period of five (5) years after purchase against defects in materials or workmanship. Akron Brass will repair or replace product which fails to satisfy this warranty. Repair or replacement shall be at the discretion of Akron Brass. Products must be promptly returned to Akron Brass for warranty service.

We will not be responsible for: wear and tear; any improper installation, use, maintenance or storage; negligence of the owner or user; repair or modification after delivery; damage; failure to follow our instructions or recommendations; or anything else beyond our control. WE MAKE NO WARRANTIES, EXPRESS OR IMPLIED, OTHER THAN THOSE INCLUDED IN THIS WARRANTY STATEMENT, AND WE DISCLAIM ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE. Further, we will not be responsible for any consequential, incidental or indirect damages (including, but not limited to, any loss of profits) from any cause whatsoever. No person has authority to change this warranty.

© Akron Brass Company. 2012 All rights reserved. No portion of this can be reproduced without the express written consent of Akron Brass Company.