

Part Number	Function 1	Function 2	Function 3	Function 4
60410008	Stow / Deploy	Fog / Stream	Left / Right	Up / Down
60410011	Fog / Stream	Left / Right	Up / Down	(None)
60410012	Osc.-Start / Pause	Fog / Stream	Left / Right	Up / Down
60410014	Stow / Deploy	High / Low Flow	Osc.- Start / Pause	Discharge On / Off
60410016	Discharge On/Off	Fog / Stream	Left / Right	Up / Down
60410018	Stow / Deploy	CAFS Wet / Off / Dry	Osc.- Start / Pause	Discharge On / Off
60410023	Fog / Stream	Left / Right	Up / Down	(None)
60410024	Fog / Stream	Left / Right	Up / Down	(None)
60411000	Stow / Deploy	Osc.- Start / Pause	Fog / Stream	Mini Joystick
60411003	Stow / Deploy	Fog / Stream	Mini Joystick	(None)
60411005	Discharge On/Off	Fog / Stream	Mini Joystick	(None)
60411006	Stow / Deploy	Fog / Stream	Mini Joystick	(None)