



Flat Disperse Fog Ring Installation Instructions for the Style 3293 30-125 gpm FireFox™ Nozzles

DISASSEMBLY 30-125 GPM NOZZLE

1. Remove the two socket head cap screws that hold the turbine teeth retaining ring.
2. Remove the turbine teeth retaining ring and turbine teeth.

REASSEMBLE 30-125 GPM NOZZLE

1. Install the flat disperse fog ring using the same socket head cap screws removed in disassembly.

Note: Use Loctite 222 or PermaBond 113 on screw threads.

2. Test nozzle for full movement and desired flow.



PHONE: 330.264.5678 or 800.228.1161 | FAX: 330.264.2944 or 800.531.7335 | akronbrass.com

REVISED: 8/11

WARRANTY AND DISCLAIMER: We warrant Akron Brass products for a period of five (5) years after purchase against defects in materials or workmanship. Akron Brass will repair or replace product which fails to satisfy this warranty. Repair or replacement shall be at the discretion of Akron Brass. Products must be promptly returned to Akron Brass for warranty service.

We will not be responsible for: wear and tear; any improper installation, use, maintenance or storage; negligence of the owner or user; repair or modification after delivery; damage; failure to follow our instructions or recommendations; or anything else beyond our control. WE MAKE NO WARRANTIES, EXPRESS OR IMPLIED, OTHER THAN THOSE INCLUDED IN THIS WARRANTY STATEMENT, AND WE DISCLAIM ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR ANY PARTICULAR PURPOSE. Further, we will not be responsible for any consequential, incidental or indirect damages (including, but not limited to, any loss of profits) from any cause whatsoever. No person has authority to change this warranty.

© Akron Brass Company, 2011 All rights reserved. No portion of this can be reproduced without the express written consent of Akron Brass Company.